PIONEER TX-9100

FW
KUW
KCW
FVZW

FM FRONT END AWB-018

AM/FM TUNER ASS'Y AWE-026

LAMP BOARD ASS'Y

POWER SUPPLY CIRCUIT ASS'Y AWR-028

MPX AF AMP ASS'Y AWD-002

VOLUME HEADPHONE AMP ASS'Y AWM-038

LEVER SWITCH CIRCUIT ASS'Y AWS-032

MUTING CIRCUIT ASS'Y AWM-044

POWER SUPPLY CIRCUIT FOR 120V MODEL

SWITCHES
S_1 FUNCTION
(AM position)
1. AM
2. FM AUTO
3. FM MONO.

S_2 POWER
(OFF position)
OFF ↔ ON

CAPACITORS
IN μF UNLESS OTHERWISE NOTED. P=pF.

RESISTORS
IN OHM, 1/4 W, ±5% TOLERANCE UNLESS OTHERWISE NOTED. K=KΩ, M=MΩ.

NOTES
→A : DC CURRENT AT NO INPUT SIGNAL.
(V) : DC VOLTAGE AT NO INPUT SIGNAL.
[V] : SIGNAL VOLTAGE AT 100% MOD.

NOTE
De-emphasis switch of MPX AF UNIT is factory-setat:
75μs for FW model.
50μs for FVZW model.

NOTE
Fuse (F_7*) is attached only to CSA approved version.

TA7061AP
HA1138
PH5052A
PA1310P
2SC710 2SA725 2SC711 2SC1312 2SC738
2SC1318
2SC1384
2SC945 2SA733
2SC1342 2SC1344
2SD313
2SK30A
TA7060P
KML6607
3SK39
3SK45